



Opus 150 Christ Church Episcopal Philadelphia, PA 49 Stops, 44 Independent Voices, 3,095 Pipes

Great, Manual II Prestant 16' Octave 8' Gambe 8' Harmonic Flute 8' Bourdon 8' Octave 4' Spire Flute 4' Twelfth 2 2/3' Fifteenth 2' Mixture IV-VI (1 1/3') French Trumpet 8'	Chaire, Manual I on gallery railing Prestant 8' Gedackt 8' Quintadehn 8' Octave 4' Rohr Flute 4' Quinte 2 2/3' Superoctave 2' Block Flute 2' Terz 1 3/5' Mixture IV (1') Dulcian 16'
, ,	
1	

Swell, Manual III, enclosed
Bourdon 16'
Violin Diapason 8'
Viole de gambe 8'
Voix céleste 8'
Cor de Nuit 8'
Dulciane 4'
Flûte octaviante 4'
Nasard 2 2/3'
Octavin 2'
Tierce 1 3/5'
Plein jeu IV (2')
Bombarde 16'
Trompette 8'
Hautbois 8'

Pedal
Resultant 32'
Open Bass 16'
Prestant 16' (Gt.)
Violonbasse 16'
Soubasse 16'
Octave 8'
Violoncelle 8' (ext.)
Bourdon 8' (ext.)
Octave 4'
Posaune 16'

Trommet 8' (ext.)

Couplers: Chaire to Great Great to Pedal
Swell to Great Chaire to Pedal
Swell to Chaire Swell to Pedal
Swell to Pedal 4'

Accessories: Wind Stabilizer Balanced Swell Pedal

General Tremulant Cymbelstern Chaire Tremblant doux Rossignol

Key Action: Direct mechanical (tracker), except for the largest pipes of the organ.

Stop Action: Solenoids, electrically controlled.

Combination action: 200 levels of memory with appropriate thumb pistons and toe studs, Sequencer.

Casework: A main case re-using the existing historic case, and a new Chaire case on the gallery railing. Key Desk: Detached from the main case, three manuals and pedal; manuals 61 keys CC - c4, naturals covered with cowbone, sharps of ebony; Fisk pedalboard 32 keys CC - g1.

Front Pipes of polished tin.